

AIR CYLINDER LEAKING

COMPLAINT:

Driver reports that the slider lock mechanism, or the air actuated king pin lock mechanism is not working properly.

CONDITION:

The slider lock or the air actuated king pin lock mechanism is not opening/closing when actuated.

DIAGNOSIS:

The air cylinder, the air lines or one of the fittings is leaking air.

THE CURE:

Repair/Replace any component that is leaking air.

ADDITIONAL INFORMATION:

1. [Fontaine Fifth Wheel Instructions Handbook - Section II](#)
2. [Air Cylinder Identification Chart](#)

TYPICAL ACTION DESCRIPTION:

Inspected air cylinder and found air leak. Replaced fifth wheel air slide cylinder (or air actuated lock mechanism cylinder).

WARRANTY:

See [Warranty Standard](#); or [Warranty Claim Procedure / SRT Chart](#) for additional information.

GENERAL COMMENTS:

Videos, Technical Bulletins and Instruction Handbooks for all necessary maintenance and repair of Fontaine Fifth Wheel products are available at no charge by calling (800) 874-9780.