

TECHNICAL BULLETIN

TB-037 • December 2007

The following illustrations show the product serial number location for No-Slack® Fontaine fifth wheels.

Note the difference in location between old & new style.

Old style serial number (before 11/27/00).

Serial number located on small rectangular tag on front of top plate.


Note: position 3 and 4 of the serial number indicates the year built.



New style serial number (after 11/27/00).

Serial number engraved directly into the right side of fifth wheel skirt.

Note: position 5 and 6 of the serial number indicates the year built.



The following illustration shows the product serial number location for 3000 Series fifth wheels.

Serial number engraved directly into the left side of fifth wheel skirt.

Note: position 5 and 6 of the serial number indicates the year built.

